



PROJECTION UMBRELLA 18882



USE

Please note: the shaft does not have a stopper or handle at the end. This is intentionally like this as the umbrella is for photographic purposes only i.e. it can be used in a tripod. The Projection Umbrella is for reflection only – it is definitely not intended for handling or play.

The Projection Umbrella is for indoor use only.

Make sure the projector is not left running so near to the projector for long periods that this would risk burning/damaging the umbrella. Remember that projectors become hot with use. Maintain a safe distance between the umbrella and the projector.
Make sure the client is safely positioned so as not to touch the projector or the umbrella handle.

SAFETY

Always supervise the use of this product.