


# **LED ROPE LIGHT 18960**



## **CONTENTS**

Your LED Rope Light is supplied in one box with a controller and mains plug attached

### **INSTALLATION/OPERATION**

Remove all packaging (clear tape around coiled lights).

Install in a suitable place, making sure that the plug can be plugged in without placing any strain on the cable.

Make sure the position of the rope light does not represent a hazard e.g. do not place where someone could trip over the rope or get caught up in it.

The use of a safety cut out device or circuit breaker is strongly recommended.

There is no ON/OFF switch – use the controller to operate.

The controller has the following options:

- 1. COMBINATION
- IN WAVES
- SEQUENTIAL
- 4. SLO GLO
- 5. CHASING/FLASH
- 6. SLOW FADE
- 7. TWINKLE/FLASH
- STEADY ON

Press the button at the top to scroll through and select from these options.

These lights may be used outdoors provided that appropriate advice and assistance is taken from a suitably qualified electrician. The plug and controller must always be kept dry and safe.

Do not install under carpets or matting or in a place where the rope light could be stood on. If suspending the lights, make sure the fixtures used (to be purchased separately) are capable of holding the product's weight (approximately 3kg)

**IMPORTANT**: The LED Rope Light should not be bent – it may be gently curved and positioned in gentle waves but not bent at acute angles. Bending the LED Rope Light at acute angles is likely to break the lights inside and cause whole sections of lights to stop lighting up.

#### **CARE & MAINTENANCE**

Switch off after use.

In the unlikely event of product failure, check the plug fuse.

Do not attempt to repair this product yourself.

Replace any damaged rope lights as soon as possible.

Cease use if the product becomes damaged.

#### **SAFETY**

Always supervise the use of this product.

Do not attempt to modify any of the wiring.

Although safe to handle, this product is recommended for decorative purposes – it is NOT a toy and should not be played with.

## **SPECIFICATION**

Colours may vary

Rope light: 1.2cm diameter x 10m

Double isolated

**IP44** 

230V 21.6W 50Hz

Plug fuse: 13A

Plug conforms to BS1363/A Controller: hardwired to lights

Input: 230V-50Hz 0.8A

Output: 2 x 0.4A

Cable: 2 x 1.0mm<sup>2</sup>