



1. Product Name

Rainbow in my Room

2. Product Code

19460

3. Colour

White

4. Brief Description

A little bit of affordable and attainable magic. Now includes a sunlight rainbow crystal – position in a sunny window and watch the rainbows dance around your room!

5. Contents

1 x Rainbow in my Room with crystal

This product requires, but does not include, 4 AAA batteries

6. Snoezelen® Stimulations

Visual

7. Best Use

Use in a darkened environment indoors.

8. Compatible ROMPA® Products

ROMPA offer a range of projection and equipment for visual input. Please see www.rompa.com for the full product range.

9. Starting Up

Put the Rainbow in my Room on a stable surface and use under supervision.
Position the crystal on a window to create prisms from sunlight.

10. Detailed Description

The Rainbow in my Room has two modes, instant or fade. Creates enchanting effects for visual stimulation. Projects a realistic looking rainbow onto your wall or ceiling. Perfect for bedrooms and home use. With LED lights for maintenance-free use.

11. Safety

Always supervise the use of this product

If using your own adapter – please make sure this is appropriate before use – seek advice from a suitably qualified electrician if required

For 5 years and over

12. Technical Specification

Size: 23cmL x 14cmH


4 AAA batteries required

This product meets all the requirements of a Class B digital device, Part 15 of FCC regulations


Lights: LED

13. Installation

1. Make sure product is switched OFF before installing batteries. A competent adult should install the batteries.
2. Locate the battery compartment.
3. Using a small Philips (cross-head/positive) screwdriver, remove the battery compartment cover.



4. Install 4 AAA alkaline batteries observing the polarity (+/-) indicated.
5. Replace the battery compartment cover. Do not over-tighten the screw.
6. If using an AC adapter, connect this to the AC adapter jack socket at the base of the unit.
7. Slide the Mode switch on the underside to the desired Mode: Mode 1: turns the rainbow on at once Mode 2: turns the rainbow on one colour at a time



8. Press the button on top of the rainbow to switch it ON/OFF. If left on, the Rainbow will switch itself off automatically after 10 minutes. If you are using an adapter, the unit will stay on until the ON/OFF button is pressed. Switch the product off after use to save power. In Modes 1 and 2, the product is always drawing a small amount of power so switch off after use!



14. Care and Maintenance

- Keep dry
- Do not immerse in water.
- Replace the batteries as necessary.
- Wipe clean with a very slightly damp clean cloth

Battery Care

- Install the batteries as indicated, observing the polarity +/-
- Do not mix old and new batteries
- Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel-cadmium) batteries
- Alkaline batteries are recommended for use with this product
- Remove weak or dead batteries
- Remove batteries if the product will be out of use for long periods
- Rechargeable batteries are not recommended
- Do not short circuit the supply terminals
- Do not attempt to dispose of batteries by burning them – dispose of them appropriately Use batteries of the correct specification

15. Troubleshooting

In the unlikely event that your Rainbow In My Room does not work, check:

The batteries – are they the correct way round, observing the polarity?

The batteries – are they old and in need of new ones?

The location of your product – the function of this product may be disturbed by strong electro-magnetic interference. If this does not correct itself, try the product in a different location.

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at producthelp@rompa.com



1. Nome do Produto

Arco-íris na Minha Sala

2. Código do Produto

19460

3. Cor

Branco

4. Descrição Breve

Um bocado de magia disponível e tangível!

Agora inclui cristal solar arco-íris - posicione numa janela ao sol e observe os arco-íris dançar pelo quarto!

5. Conteúdo

1 x Arco-íris na Minha Sala

Necessita 4 pilhas AAA (para ser comprado separadamente)

6. Estimulação Snoezelen[®]

Visão

7. Melhor Utilização

Use em um ambiente escuro dentro de casa.

8. Compatibilidade com Produtos ROMPA®

Veja www.rompa.com

9. Começar

Instale 4 pilhas AAA. Posicionar o cristal em uma janela para criar prismas da luz solar. Supervisione sempre a utilização deste produto.

10. Descrição Detalhada

Um bocado de magia disponível e tangível!

Agora inclui cristal solar arco-íris - posicione numa janela ao sol e observe os arco-íris dançar pelo quarto! Agora com dois modos – instantâneo ou desvanecer.

Efeitos encantadores para estimulação visual. Projeta um arco-íris que parece real para a sua parede ou teto. Mova a sua mão por baixo do sensor de movimento para ativar o arco-íris. Perfeito para quartos de dormir e uso em casa. Com luzes LED para uso sem manutenção. A partir de 5 anos.

11. Segurança

Supervisione sempre a utilização deste produto.

A partir de 5 anos

12. Especificações Técnicas


Tamanho: 23cmC x 14cmA

Este produto cumpre todos os requisitos da classe B serviço digital, parte 15 do regulamento da FCC.

Luz: LED


13. Instalação

1. Verifique se o produto está desligado antes de instalar as pilhas. Um adulto competente deve instalar as pilhas.
2. Localize o compartimento das pilhas.
3. Utilizando uma chave de estrela, remova a cobertura do compartimento das pilhas.



4. Instale 4 pilhas AAA observando a polaridade (+/-) indicada.
5. Volte a colocar a cobertura do compartimento das pilhas. Não aperte o parafuso em demasia.
6. Alterne entre dois modos mudando a posição da switch:
modo 1: liga o arco-íris de imediato
modo 2: liga o arco-íris numa cor de cada vez


Mode 1



Mode 2



7. Pressione o botão na topo do arco-íris para ligar e desligar. Se for deixado ligado, o arco-íris irá desligar-se automaticamente após 10 minutos. Se estiver a utilizar um adaptador AC, a unidade irá ficar ligado até que o botão de ligar/desligar, seja pressionado. Desligue o produto depois de utilizar para poupar energia. No modo 1 e 2, o sensor está sempre a consumir uma pequena quantidade de energia, portanto, desligue-o após a utilização!



14. Cuidado e Manutenção

Mantenha seco

Não imergir na água

Substitua as pilhas quando for necessário

Limpe com um pano ligeiramente húmido

Cuidados com as pilhas

- instale as pilhas como indicado, observando a polaridade +/-
- não misture pilhas novas com pilhas velhas
- não misture pilhas alcalinas, normais e recarregáveis
- é recomendada a utilização de pilhas alcalinas neste produto
- remova as pilhas fracas ou gastas
- remova as pilhas se o produto não for utilizado por um longo período de tempo
- não é recomendada a utilização de pilhas recarregáveis
- não coloque os terminais das pilhas em curto-circuito
- não deite as pilhas para o lume quando se desfizer delas – coloque-as no pilhão
- utilize pilhas com as especificações correctas

15. Resolução de Problemas

Na eventualidade do seu Arco-íris na minha sala deixar de funcionar, verifique:

- As pilhas – estão na posição correcta, observando a polaridade?
- As pilhas – estão gastas e são necessárias novas?
- A localização do produto – o funcionamento deste produto pode ser perturbado por fortes interferências electromagnéticas. Se isto não se corrigir automaticamente, experimente o produto em outra localização.