

SNOOGLE 19525

CONTENTS

1 x Snoogle

BEFORE PLAY

Make sure that all packaging (bags, ties etc) are removed before play Locate the opening to bring Snoogle to life – the opening for your hand is approximately 10cm behind his eyes.

CARE & MAINTENANCE

Your Snoogle can be machine washed at 30°. Snoogle is sealed up (i.e. you cannot access the interior filling and the whole cushion should be washed). Do not bleach. Wash with similar colours. Allow to air dry naturally.

SAFETY

Always supervise the use of this product. Intended for three years and over There are no detachable loose parts on this product

SPECIFICATION

Meets all the requirements of EN71 No child labour used Size: 36 x 36cm Colours may vary

