



1. Product Name

Music Trolley

2. Product Code

20450

3. Colour

Natural wood finish

4. Brief Description

Large enough to store the 24 instruments included.

5. Contents

- 1 trolley
- 24 instruments (see 'Detailed Description' below)
- 1 bag of castors
- 1 bag of fixtures – handles and screws

6. Snoezelen® Stimulations

- Sound

7. Best Use

Use the trolley to move round and store the instruments supplied. When the uppermost lid is down, some instruments can be placed on the top:



8. Compatible ROMPA® Products

See www.rompa.com for further musical instruments.

9. Starting Up

- Unpack all the components
- Attach the castors.
- Attach the handles.

10. Detailed Description

Large enough to store and compactly display the 24 instruments included. Space-saving, money saving and extremely practical. Trolley is beech with 3 drawers, a hinged lid and wheels. Instruments include: metallophone, 10 plastic chime bars, pair of claves, tone block with handle, 2 guiros, wooden block, 2 jingle sticks, jingle tree, 2 hand bells with leather strap, bell stick, 2 triangles, pair of castanets, pair of maracas, pair of finger cymbals, 4 cymbals, cymbal stand and 2 tambourines.

11. Safety

- Always supervise the use of this product

12. Technical Specification

Dimensions:	55L x 27D x 65cmH
Weight:	15.5kg
Trolley:	wood
Instruments:	wood, plastic, metal

13. Installation

- I. Unpack all the components. Your Trolley and instruments are all supplied in one outer box. Take care to check inside all the inner packaging so as not to accidentally discard any of the instruments. These are packed in several boxes/sheets of cardboard.
- II. Locate the two bags inside the uppermost compartment (lift up the top lid). One bag contains four castors (each 40mm). Attach the castors by pushing these onto the four metal rods on the underside of the Trolley – one in each corner.
- III. Using the components in the second bag, attach the two handles to the two drawers with pre-drilled holes (top and bottom). Use the two smaller screws.
- IV. Some instruments may require some minimal assembly e.g. cymbal stand.

14. Care and Maintenance

- Wipe clean using a soft cloth that has been slightly dampened with water and a very mild cleaning solution.
- Do not immerse in water.
- Keep indoors, in a dry environment, away from sources of heat.

15. Troubleshooting

Not applicable

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at producthelp@rompa.com



1. Nome do Produto

Trólei Musical

2. Código do Produto

20450

3. Cor

Acabamento em Madeira natural

4. Descrição Breve

Grande o suficiente para guardar os 24 instrumentos incluídos.

5. Conteúdo

- 1 trólei
- 24 instrumentos (veja as descrições detalhadas abaixo)
- 1 saco com rodízios
- 1 saco de acessórios de montagem – pregos e parafusos

6. Estimulações Snoezelen

- Som

7. Melhor Utilização

Utilize o trólei para movimentar e guardar os instrumentos fornecidos. Quando a tampa superior está para baixo, alguns instrumentos podem ser colocados no topo:



8. Compatibilidade com Produtos Rompa

Visite www.rompa.com para mais instrumentos musicais.

9. Começar

- Desempacote todos os componentes
- Instale os rodízios
- Instale as pegas

10. Descrição Detalhada

Grande o suficiente para guardar e exibir de forma compacta os 24 instrumentos incluídos. Poupe espaço e dinheiro. Extremamente prático. Trólei em faia com 3 gavetas, uma pega e rodas. Os instrumentos incluem: metalofone, 10 barras de carrilhão plásticas, par de claves, Bloco sonoro com pega, 2 reco-recos, bloco de madeira, 2 chocalhos, árvore chocalho, 2 sinos com faixas de pele, sinos, 2 triângulos, par de castanholas, par de maracas, par de pratos de dedos, 4 pratos, tripé de pratos e 2 tombores.

11. Segurança

- Supervisione sempre a utilização deste produto

12. Especificações Técnicas

Dimensões: 55C x 27P x 65cmA
Peso: 15.5kg
Trólei: Madeira
Instrumentos: Madeira, plástico, metal

13. Instalação

1. Desempacote todos os componentes. O seu trólei e instrumentos são todos fornecidos numa caixa. Verifique cuidadosamente toda a embalagem para garantir que não deita nenhum instrumento ao lixo. Estes estão embalados em diversas caixas/folhas de cartão.
2. Localize os dois sacos dentro do compartimento superior (levante a tampa superior). Um saco contém quatro rodízios (40mm cada). Prenda os rodízios empurrando-os contra as quatro varas metálicas na parte de baixo do trólei – um em cada canto.
3. Usando os componentes no segundo saco, prenda as duas pegas e as duas gavetas com os furos existentes (topo e fundo). Utilize os dois parafusos mais pequenos.
4. Alguns instrumentos requerem uma montagem mínima, ex: tripé dos pratos.

14. Cuidado e Manutenção

- Limpe com um pano macio ligeiramente humedecido com água e uma solução suave.
- Não submerja em água.
- Mantenha no interior, em ambientes secos, afastado de fontes de calor.

15. Resolução de Problemas

Não aplicável